


Accessories Guide



Standard

Adapter







PWR-P80-5V2A-EU




PWR-P80-5V2A-UK



PWR-P80-5V2A-US

Adapter(CN/EU/UK/US), I/P: 100-240V, O/P: 5V2A, use with DC-BK-TypeC cable

USB Cable



DC-BK-TypeC

1.0 meter Type-C cable

Sim Tray Ejector



SIM-TRAY-EJECTOR

SIM tray ejector

Hand Strap



SG-P80-HDSTP Hand Strap

Optional

Rugged Rubber Boot



RB-P80-RR

Rugged Rubber Boot, omni-directional protected, can be installed with standard VESA holder with interface- FDMI MIS-C (75x35mm), and vehicle-mounted bracket MOT-P80 that need to be purchased separately.

Holder



MOT-P80

Holder, 110*50*40*1.5

Charging Cradles & Adapters



CRD-P80-RBC

Charging Cradle for device, use with DCPWR-5V2A-(CN/EU/UK/US) adaptor and TYPE C cable.

The cradle cup has an insert that is fixed by 4 pcs screws and they must be removed in prior when charging P80 with rugged boot.



CRD-P80-INS

Insert for P80 cradle cup.

4 pcs M2*6.0 screws are necessary.

