Gamma Label



The Gamma Label is the first UHF Label designed to survive e-beam and gamma sterilization applications. It's extremely low profile and flexible for any non-metallic curved surfaces with up to 3 m read range.

With two size options, it can incorporate human readable printing, barcodes, and graphics.







Withstand e-beam and gamma sterilization







- · Healthcare devices and equipment
- · Pharmaceutical & biotech processing equipment
- Food

Performance Characteristics		
Read range ¹ (Handheld)	Up to 6.5 ft (2 m)	
Read range ¹ (Fixed)	Up to 9.8 ft (3 m)	
Polarization	Linear	
Mounting system	High performance adhesive	


1. Off metal


Functional Specifications		
RF protocol	EPC global Class 1 Gen2	
Frequency	902-928 , 865-868 MHz (Global)	
IC type (chip) ¹	MB97R8050-AP15-ES	
Memory	160-bit EPC, 176-bit serialized TID	
Face material	White thermal transfer face stock	

^{1.} The chip data retention is up to 50 years, based on chip operating under general environment conditions.

Radiation Pattern

Off metal-Horizontal / Vertical


















Environmental Specifications		
Operational temperature	-40°C to +85°C	
Survival temperature	-40°C to +85°C (long term)	
Resistance compliance	Gamma, E-beam sterilization	
Shock (drop)	3 ft (1 m) to concrete/granite	
Vibration	MIL-STD-810G	
Printer compatibility	Sato CL4NX, CT4-ex-RF Zebra ZD500R, ZT600, ZT400	

Industry Compliance		
RoHS	EU Directive 2011/65/EU	
CE	Yes	
ATEX/IECEx	Compliant	
Warranty	1 year	

Order Information		
X6101-GL011-F1	Gamma Label (75 x 20)	
X6201-GL011-F1	Gamma Label (101.6 x 50.8)	
Optional service	encoding / printing	



Product Dimensions and Weight 2.95 x 0.79 x 0.008 Dimensions (in) 4.0 x 2.0 x 0.008 +/- 0.02 Tolerance Dimensions (mm) 75 x 20 x 0.2 101.6 x 50.8 x 0.2 Tolerance +/- 0.5 Delivery format On roll Quantity per roll (small) 1000 Quantity per roll (large) 2000 Weight (roll) 2.54 lbs (1.15kg)



Installation Instructions

Instructions for optimal performances:

- Clean the surface using Isopropyl alcohol, alcohol pad or equivalent solvent to ensure surface is free from dirt, dust, oil and misc debris that may affect adhesion.
- oil and misc, debris that may affect adhesion.

 2. Handle the label by edges, peel release liner from back ensuring not to touch the adhesive.
- 3. Place the label in desired tagging location and firmly apply even pressure to the label for 5 seconds.
- 4. Do not disturb newly mounted label for at least 15 minutes to ensure proper adhesive seating.